

Installation Guide

PEX-a Tubing with F1960 Expansion Fitting (Poly Alloy/Lead-free Ecobrass)



Step 1: Cutting the tubing

Using the RIIFO PEX tubing cutter, cut the tubing squarely with speed and precision.



Step 2: Sleeving

Choose the correct size expansion sleeve for tubing and insert until it reaches the tab on the sleeve.



Step 3: Expanding

Using an approved manual or cordless expansion tool, insert the tool into the PEX tubing and expand. Expand until the tubing/sleeve are snug with the expander tool.



Step 4: Insertion

Once the tubing and sleeve are expanded, quickly insert expansion fitting into the expanded tube/sleeve until it hits the shoulder. Hold fitting in place until the tubing contracts and secures around the fitting.



Step 5: Inspection

Verify the connection is secure, the tubing is fully inserted, and is fitted tightly around the fitting.

*Test all completed connections in accordance with the local authority having jurisdiction



RIIFO